

DDS3v8 WIRING DIAGRAM TO NON-AQUAMIST SYSTEM

TRIGGER MODE: PWM PUMP- :: FAILSAFE: BOOST CUT

